

# Product Specifications

## FlashLink BLE Logger

<b>Measurement Range</b>	-22°F to 140°F (-30°C to 60°C)
<b>Accuracy</b>	±0.9°F from -22°F to 140°F (±0.5°C from -30°C to 60°C)
<b>Temperature Resolution</b>	0.1°F/°C
<b>Data Capacity</b>	60,000 data points
<b>Logging Interval</b>	5 minutes
<b>Start mode</b>	Manual
<b>Transmission Range:</b>	2 seconds interval/~100ft (30.5m) at sight
<b>Shelf Life</b>	2 year
<b>Battery</b>	3.0v lithium battery
<b>Dimensions/Body</b>	1.38in x 0.43in (35mm x 11mm)
<b>Casing</b>	ABS plastic
<b>Waterproof Rating</b>	IP65
<b>Weight</b>	0.64 oz (18 grams) with battery
<b>LED</b>	Green
<b>Certification</b>	CE Mark, FCC
<b>System Requirements</b>	Requires BLE Gateway Model 40993 to read and save data to the cloud
<b>Bluetooth Connection</b>	Bluetooth 4.0/5.0
<b>On-Line Tracing</b>	Customized web portal

**Kroger BLE Logger**

**SHIPPER INSTRUCTIONS**

1. Fill out the white shipping label below the BLE logger.
2. Remove peel away barcode label from BLE logger, apply to shipping document.
3. Press and hold START button until green ACTIVE LED stops flashing, then release the button.
4. After activation green LED will flash every 2 seconds for 30 seconds.
5. Use adhesive strips on back of card to attach BLE logger to the last pallet next to the door on top edge of pallet or carton.

**INSTRUCCIONES DEL EMBARCADOR**

1. Llene la etiqueta de envío blanco debajo del registrador BLE.
2. Retire la etiqueta de código de barras despegable del registrador BLE, colíquela al documento del envío.
3. Mantenga presionado el botón de INICIO hasta que el LED verde ACTIVO deje de parpadear, luego suelte el botón.
4. Después de la activación, el LED verde parpadeará cada 2 segundos durante 30 segundos.
5. Utilice las tiras adhesivas del reverso de la tarjeta para fijar el registrador BLE al último palet junto a la puerta en el borde superior del palet o caja.

**ATTENTION BLE LOGGER HERE**

**RECEIVER INSTRUCTIONS**

1. Complete incoming documentation and inspection of the shipment.
2. Retire the green instruction card with the BLE logger and place into the designated recycling box.

**INSTRUCCIONES DEL RECEPTOR**

1. Completar la documentación entrante e inspección del envío.
2. Retire la tarjeta de instrucciones verde con el registrador bluetooth y colóquela en la caja de reciclaje designada.

**MODEL 40980**

FDA Compliance: BFCAD0 140

FlashLink BLE Logger

START

62401972

UNITED STATES OF AMERICA  
E PLURIBUS UNUM  
QUARTER DOLLAR

### Model 40980

- Single-use BLE temperature data logger
- Tracks environmental conditions inside vehicles during shipment
- Wirelessly transmits data by Bluetooth to Gateway device
- No need to locate logger for downloading
- Temperature and location data stored in cloud-based FlashTrak web portal

DeltaTrak manufactures and operates under an ISO 9001:2015 registered quality management system

SS 40980 Kroger 24K1

